

Instructions for software update download and micro-SD card format for Luna Optics **G3** models:

1. Download the **.bin** file onto your computer
2. Remove the micro-SD card from the device, insert it in your computer using the supplied USB adapter drive and copy the downloaded **.bin** file onto the card (**IMPORTANT:** file must be copied in main/root directory - not in any folders).

NOTE: if you have any files on your SD card that you wish to save, please transfer them to your computer now, because they will be deleted after update process is finished.

3. Insert the micro-SD card back into the unit and turn the device ON
4. Allow the update to run (on some models LED lights will be half-lit during the update process, on some models LED lights will be flashing on and off during update) After update is done the device will turn on.
5. Press onto the Menu Controller for 2sec – Main Menu will appear – scroll down the menu with the Menu Controller until you see **Format** – short press Menu Controller to select it, then scroll down to **OK** and again short press Menu Controller to select it. On some models the warning window will appear advising that all files will be erased. Select **YES** or **OK** and the card will be formatted.

If you do not format the card after the update the update will re-run each time you start the device.

If you have any questions, please call us at +1-972-722-1100 or e-mail us at info@lunaoptics.com